

WG-50 Upgrade Method

Firmware upgrade steps are as following:

1, Ready a Micro SD(TF) card and format the Micro SD card

2, Copy New Firmware files in SD card:

A: WG50bin

B: DRAMPARA.txt.


C: ISP.BIN.


3, Insert this Micro SD card in device, Press below buttons one by one in order:



4, After pressing above button in order, screen will show "FW UPGRADE", see PIC.

Then



5, Press " button, Device is upgrading. Have to await 40seconds.
Once upgrade is completed, device will shut down automatically.

6, Power On device again. Upgrade is completed.

*Upgrading is needed only when an improved firmware is available.

*Keep power on when device is upgrading. Otherwise, device have to return manufacturer to repair when device data is broken in upgrading.